

SUBJECT: OH6 Burner Wiring

Got Your Wires Crossed? There has been some confusion lately with the **OH6 Burner Wiring**. Installers have been wiring the line voltage (red and white wires) to the Honeywell primary control auxiliary 1 & 2 terminals. This is incorrect. When installing a **Beckett Burner**, the red and white wire from the control board is to be connected **inside** the burner junction box to the Honeywell primary control black and white wires. If a **Riello Burner** is installed, the red and white wires are connected to the black and white wires on the switching relay.

Engineering is revising the wiring diagram to make it clearer and is looking into adding a connector to the burner and furnace wiring harnesses to make for a quicker and easier installation of the burner.